

UB- 5A, RAF-11

UB/5A

Displacement transducer for measurement of crack opening, measuring range 3-8 mm, sensitivity 2.5 mV/V

RAF-11

Fixing Jig to be with UB-5A



UB- 5A, RAF-11

